

ZCH PUMPS

6x6

AMPCO PUMPS COMPANY PARTS BREAKDOWN

PARTS BREAKDOWN		
DETAIL	REQ.	
NO.	NO.	PART NAME
24	1	GASKET (COVER/STUFFING BOX)
23	1	STUFFING BOX
21	1	O-RING (SHAFT/SLEEVE)
20¹	1	PIPE PLUG (DRAIN)
19	1	MOTOR
18B	4	CAP SCREW (COVER/ADAPTER)
18A	8	CAP SCREW (CASING/COVER)
17	4	CAP SCREW (MOTOR/ADAPTER)
16¹	2	DRIVE SCREW
15¹	1	NAME PLATE
14	1	MECHANICAL SEAL
13	1	IMPELLER KEY
11	1	GASKET (SLEEVE/IMPELLER)
10	1	O-RING (IMPELLER SCREW)
9	1	GASKET (CASING/COVER)
8	1	SLINGER
7	1	IMPELLER SCREW
6	1	SHAFT SLEEVE
4	1	ADAPTER
3	1	IMPELLER
2	1	COVER
1	1	CASING

1NOT SHOWN

NOTE: Please be sure to always include pump type, size, and serial number with any reference to above numbers and names.