


ZPH PUMPS

AMPCO PUMPS COMPANY PARTS BREAKDOWN



DETAIL NO.	PART NAME
27A	KEY - COUPLING
27	KEY - COUPLING
26	SHAFT SLEEVE
25A	SHAFT GREASE SEAL
21	GASKET
21C	GASKET
21B	GASKET
21A	GASKET
19B	PIPE PLUG
19A	PIPE PLUG
19	PIPE PLUG
17F	CAP SCREW
17C	CAP SCREW
17	CAP SCREW
15	BEARING CAP
14A	BALL BEARING WITH MECHANISEAL & DUST SEAL
14	RADIAL-THRUST BEARING
13	GLAND - SPLIT
12	PACKING RING
11	SEAL RING
10	THROAT BUSHING
9	IMPELLER SCREW
8	SHAFT SLEEVE
7	WEARING RING - REAR
6	WEARING RING - SUCTION
4	PEDESTAL
3	IMPELLER
2	COVER
1	CASING

NOTE: Please be sure to always include pump type, size, and serial number with any reference to above numbers and names.